


FIG. 1


FIG. 2



FIG. 3

FIG. 4

※ 「→」 IN SEQUENCE DENOTES Dch PACKET COMMUNICATION.
 「□」 INDICATES DATA CONTENTS OF Dch PACKET AND
 「■」 INDICATES Bch CHANNEL IN USE.

FIG. 5




FIG. 6






FIG. 7

FIG. 8



※「→」 IN SEQUENCE DENOTES Dch PACKET COMMUNICATION. 「□」 INDICATES DATA CONTENTS OF Dch PACKET AND 「■」 INDICATES Bch CHANNEL IN USE.

[illegible]

※「→」 IN SEQUENCE DENOTES Dch PACKET COMMUNICATION.
「」 INDICATES DATA CONTENTS OF Dch PACKET AND 「」 INDICATES Bch CHANNEL IN USE.